

## CAST IRON WALLMOUNT INSTALLATION



### HOMEOWNERS

Please read before installation.

#### Step: 1

BEFORE INSTALLING WALL-MOUNT SINK INSTALLATION (mounting bracket included) 1. Place the mounting bracket in the installation location and mark the wall through each of the mounting holes. Important: The sink should be anchored to two wall studs. Locate and mark the position of the wall studs to which you will fasten your sink by listening for a solid sound as you knock on the wall or by using a stud finder. If the studs in your bathroom do not line up to the mounting location for your sink, wood blocking can be installed between the studs using standard 2 x 4's. 2. Drill mounting holes for the anchor or lag bolts using the bracket as guides. If the wall is tile, use a masonry drill bit.

#### Step: 2

Properly locate and level the mounting bracket(s) onto the finished wall and mark out all bolting holes at each mounting location.

NOTE: THE SINK BRACKET(S) IS TO BE ANCHORED ONTO A MINIMUM SIZE 2"X 4" WOOD NAILER INSTALLED AT THE DESIRED HEIGHT BEHIND THE FINISHED WALL LOCATED IN BETWEEN EXISTING VERTICAL STUDS AS REQUIRED.

Level and attach the mounting bracket(s) onto the finished wall using lag bolts to secure into the wood nailer at the desired elevation.

#### Step: 3

Secure the mounting bracket(s) to the wall with the anchor bolts. /

After inserting the first fastener, verify that the bracket is level. When the bracket(s) is properly aligned insert the remaining fasteners.

Lower the back of the sink onto the wall mounting bracket(s) while lining up all the sink hanging clips. Firmly push the sink downward onto the bracket until tight against the wall.

#### Step: 4

. Install the new faucet and drain assembly according to the installation instructions.

NOTE: SOME WALL MOUNTED SINKS INCLUDE A PROTECTIVE TRIM PIECE TO COVER THE PLUMBING LINES. THESE TYPICALLY ATTACH DIRECTLY TO THE WALL FRAMING WITH LAG BOLTS.

Connect the hot & cold water supply lines (not included) to the faucet as recommended.

Connect the drain p-trap and associated piping (not included) onto the pop-up drain assembly tail piece as recommended.

Separately and slowly open the hot and then the cold water supply lines checking all pipe connections for leaks.

While filling the sink basin run water through the drain piping checking all pipe connections for leaks.

PLEASE CONSULT A LICENSED PLUMBER IF YOU ARE UNFAMILIAR WITH THIS TYPE OF INSTALLATION.

IT IS RECOMMENDED THAT A LICENSED PLUMBING CONTRACTOR INSTALL THIS ITEM TO MAINTAIN WARRANTY.

### WARNING

Before installation, please inspect your product for any damage that may have occurred during shipping. If the product was damaged in the shipping process or your product needs to be returned for another reason, it must be in the original packaging. If the product is not returned with the original packaging you may not be eligible for a refund of the purchase price. Return fees may apply. Please contact your dealer for more information.